




spare parts list
vari-spreader
spreading unit


serie 22114



serial number 22114

F10

BUILDING BLOCK 90002232



SU

bestelnummer
order number
num. à commander
Bestellnummer



B=79220016
D=79220018
E=79220019

| | | |
|------------|---|------------|
| 900.02232 | 1 | 8.8-M14x65 |
| 302.97.365 | 2 | 8.8-M5x25 |
| 302.97.525 | 3 | 8.8-M10x20 |
| 302.98.120 | 6 | 8.8-M6x25 |
| 302.98.625 | 1 | 8/M10 |
| 305.96.100 | 2 | 8/M5 |
| 305.96.500 | 3 | 8/M14 |
| 305.97.300 | 2 | 8/M6 |
| 305.97.600 | 1 | A 5,1 |
| 314.96.500 | 3 | 10,5 |
| 314.97.100 | 4 | |
| 900.15671 | 1 | |
| 900.20041 | 1 | |
| 900.21406 | 1 | |
| 900.70437 | 1 | |
| 900.70589 | 1 | |

70.003.540-2


serial number 22114

F12

SU

BUILDING BLOCK 90002232

bestelnummer
order number
num. à commander
Bestellnummer



A=79220037
B=79220026
C=79220027
E=79220029
F=79220036
79220014X

| | | |
|------------|---|-------------|
| 900.02232 | 1 | |
| 178.70261 | 1 | |
| 178.70401 | 1 | |
| 178.70985 | 2 | |
| 178.70986 | 2 | |
| 194.20084 | 1 | |
| 302.96.825 | 1 | K100-M8x25 |
| 303.63.830 | 2 | 10.9-M8x30 |
| 303.97.150 | 1 | 10.9-M10x50 |
| 305.97.100 | 1 | 8/M10 |
| 305.97.800 | 2 | 8/M8 |
| 308.53.655 | 1 | 6x55 |
| 308.95.155 | 1 | 10x55 |
| 417.02.899 | 4 | M8x1,25 |

79.993.540-4